

INSTALLATION INSTRUCTIONS

Dear Customer, We are pleased that you have chosen Astonlouis laminate flooring .We recommend that you read the instructions carefully before starting the installation

Use a damp-proof foil mattress, a standard mattress. Do not use glue, screws or nails during installationNever hit the parquets directly with a hammer. Always use plastic wedges to protect the edges of the parquets.

During the installation, leave 1cm gap on all edges at the end and beginning of the wall.

Follow the instructions of the underfloor heating company in order to be applied on the underfloor heating system.For underfloor heating, the temperature should be lower than 24 ° C.

Place AstonLouis Parquet boxes horizontally in the area to be install 48 hours before installation. Put the boxes in the middle of the rooms, not against the wall. Unpack the packages just before installation. Check each flooring carefully. Do not install defective parquets. Defects in the ground must be repaired. The floor should be clean and dust-free. The height difference on the ground must be a maximum of 2 MM

Ideal Assembly conditions:The temperature is between 16 ° C and 21 ° C and the humidity is 50% -60%. Moisture of concrete should not exceed %25. It uses Uniclick system. The parquets are attached to each other by the female-male system. This system is fast and perfect. Use impact chock.Hit the short edge with small strokes. Never hit hard otherwise you will damage the parquet.On the long edge hit the Parquet repeatedly. Gently hit the parquets until they overlap and repeat this at 40cm until the entire system is locked. Leave space on each wall, heating pipes and any obstacle foresee expansion. The spaces left for expansion can be hided by the skirtings. Never fix the parquet to the skirting. You should use a T-profile on floors longer than 10 meters. The easiest way to assemble parquets is to start by passing positive side to negative side.